


ON OFF


Wi-Fi Breaker



Parameter:
 Rated Voltage: AC100-240V
 Rated Current: 10A/2400W
 Wireless Type: WiFi 2.4GHz
 802.11b/g/n
 Material: ABS+PC
 Size: 88* 38*22mm

checklist: before using the device

- Your smart phone or tablet has connected to a 2.4G WiFi with internet.
- You have the correct WiFi PWD.
- Your smart phone or tablet must have access to APPStore, Google Play.
- Your router is MAC-open.




User Guide

- 1 Start with "Smart Life" APP.



- 2 Register an Smart Life.
- 3 If you have Smart Life, just log in.
- 4 Power up.


ON/OFF operating principle:
 The connected appliances work/stop through live wire power on/off .



4.1 Appliance wiring instruction.



4.2 Ceiling lamp wiring instruction.




4.3 One wire wiring instruction.



*Note: The WiFi Switch must be powered up by N and L wires.

- 5 Press and hold the button for about 7 seconds until the WiFi green LED blinks fast.



- 6 Enter the App, tap "+" in the upper right of the page to enter network connection page.

- 7 There are two network connection methods (Normal mode and AP mode). Normal mode is default. Users could tap the upper right corner to switch the connection method to AP mode.

- 8 Please make sure the device's indicator light rapidly flashes (2 times per second), tap to go on to the next step

- 9 If indicator light is not rapidly flashing, tap "how to set indicator light as rapid flashes" to view operation processes

- 10 Input your WiFi password.

- 11 Name your device.

- 12 the device is online.

TROUBLESHOOTING

Q: How to set indicator light as rapid flashing?

- Power on device . power off after 10s and then power on.
- hold the reset button for 5s.
- Confirm indicator light is now rapidly flashing.

Q: How to set indicator light as slow flashing?

- Power on device. power off after 10s and then power on.
- hold the reset button for 5s.

- ③ Confirm indicator light is now rapidly flashing.
- ④ Hold reset button for 5s until indicator light is slowly flashing


The new added device needs 1 min to connect to WiFi and the Internet if it stays offline for a long time please judge the problem by the WiFi LED status.

WiFi LED quickly blinks one time every second;
 WiFi Switch failed to connect to your WiFi

- ① Maybe you have entered wrong WiFi password.
- ② Sonff is too far away from your WiFi please take it closer.
- ③ Make sure your router is MAC -open. if still failed, try to open a mobile hot spot and add again.

ON OFF

Wi-Fi 通断器




产品参数：

输入电压: AC100V ~240V
最大功率: 10A/2400W
WiFi标准: 2.4GHz802.11b/g/n
外壳材料: ABS+PC
尺寸规格: 88*38*22mm

使用该设备前请检查以下事项：

- 您的智能手机或平板已连接上一个能上网的2.4G WiFi.
- 使用安卓系统的手机或平板,系统必须是4.0以上版本.
- 使用苹果手机或iPad必须能够访问APP商店并下载APP.
- 如果您的无线路由器设置了MAC地址过滤,请先进入路由器后台关闭MAC过滤功能.




产品使用说明书

- 1 在各大应用市场搜索“智能生活”下载安装。



- 2 安装过程如有提示权限请求请选择允许。
- 3 注册账号并登录智能生活。
- 4 按照外壳指示正确接线。本开关必须零火线供电。严禁带电安装！


注：本设备的开关原理是通过控制电路火线的通断,从而实现电器工作和停止.本设备必须零火线供电,设备才能正常工作.



4.1 控制电器电路正确接线示意图。



4.2 控制LED吸顶灯正确接线示意图。




4.3 单火线输出正确接线示意图。



注意:本设备必须零火线接入才能正常使用,且零火线不要接反。

- 5 完成接线后通电。设备默认来电为关,可以在APP更改设置为未来开店或保持。



- 6 进入应用程序,点击“+”在页面的右上角进入网络连接页面。

- 7 有两种网络连接方法(普通模式和AP模式).普通模式是默认的.用户可以点击右上角,将连接方法切换到AP模式。

- 8 在正常模式下,请确保设备指示灯快速闪烁(每秒2次),点击进入下一步。

- 9 如果指示灯不是快速闪烁,点击,“如何设置指示灯为快速闪烁”查看操作过程。如何将指示灯设置为快速闪烁。

- 10 输入手机当前连接的WIF密码。
- 11 给设备命名,完成添加。
- 12 可进行远程遥控。

常见问题及解决办法

Q:如何将指示灯设置为快闪

- ① 将设备接通电源,10秒后断电再接通电源。
- ② 长按复位键5秒。
- ③ 确认指示灯快闪。

Q:如何将指示灯设置为慢闪

- ① 将设备接通电源,10秒后断电在接通电源。
- ② 长按复位键5秒。
- ③ 确认指示灯快闪。
- ④ 再次长按复位键5秒,直至指示灯慢闪

注:新增加的设备需要1分钟连接WiFi和互联网,如果长时间没有连上,请通过WiFi状态来判断问题。

添加设备成功后,显示离线,无法控制?

- ① 可能是wif密码输入不正确。
- ② 可能是设备离您的路由器太远,信号太弱,或环境有干扰。
- ③ 检查您的路由器后台是否开启MAC地址过滤,如有,请关闭。